

www.nav-tv.com info@nav-tv.com


W204-12 DYNAMIC Kit

NTV-KIT461



Overview

The W204-12 DYNAMIC kit allows the user to add up to 3 video inputs and a backup camera input to the factory media screen in select Mercedes vehicles. This kit installs behind the radio and video cables must be run up behind the factory screen. The guidelines presented while in reverse will be active (ie: move with the steering wheel) when the CAN connection is made.



Interface Connectors						
IR Eye Power/CAN Rear Camera Power Rear Camera Power NDUT AV IN/OUT						
LVDS COMM Cable LVDS Video OUT (to monitor) LVDS Video IN (from factor	r y)					
LVDS COMM Cable Status LEDs Dip Switches						
Dip Switch Settings*						


Dip SW:	1	2	3	4	5	6	7	8
UP	Enables	Enables	Enables	Enables	For	7″	Deactivates	Кеер
	RGB	V1	V2	V3	Scre	en	R/V (cam)	UP
DOWN	Skips	Skips	Skips	Skips	For 6.5"		Activates	Кеер
	RGB	V1	V2	V3	Scre	en	R/V (cam)	UP




*Note: after adjusting Dip Switches, you must disconnect and reconnect power to the interface or the change will not be implemented.

Installation

- Remove the factory radio. This normally requires removing trim panels and a series of screws. Disconnect all harnesses connected to the COMMAND radio and set the radio aside.
- 2. Locate the *white connector* inside the factory 44-pin main COMMAND radio plug. Disconnect the white connector via the retaining clip.
- 3. Separate the white cover from the black plug by releasing the clip on the side.









- 5. Insert the same connector (from step 4) back into the main factory 44-pin connector until it clicks into place.
- 6. Connect the factory black 12-pin connector (removed from the white clip in step 3) into the female end of the supplied *Power/CAN T-Harness*.
- 7. From the same provided *Power/CAN T-Harness*, locate and solder the following wires to the car*:


W204-12 Wire Label	Connect to CAR's	Location	
GND (black)	Ground (-)	44-Pin main plug	
ACC (red)	Accessory wire (+)	Cigarette lighter	
CAN1-L (brown)	CAN-L (Yellow/Brown) <i>twisted</i>	<i>Pin 9,</i> 44-Pin main plug	
CAN1-H (red)	CAN-H (Yellow/Red) <i>twisted</i>	<i>Pin 11</i> , 44-Pin main plug	

*Note 1: CAN wire color will vary per vehicle, but they will be twisted. *Note 2: Connect the CAN wires behind the *radio, not at the screen!*

- 8. Connect the white 16-pin power connector to the port on the w204 interface labeled 'Power'.
- 9. Connect the provided LVDS COMM Cable between the W204-12 interface at the port labeled 'LVDS OUT' and the provided SUB-Board. This connector is keyed, and can only fit in one direction and one port.
- 10. Connect the factory LVDS Video cable to the green LVDS port on the provided SUB-Board:
- 11. Connect the supplied *LVDS Video Cable* to the 5-pin plug on the SUB-Board used from step 9 and connect the other white end to the factory Mercedes screen at the appropriate port.
- 12. Connect the AV Input cable to the port on the W204 interface labeled 'AV IN/OUT'. If you're only connecting a reverse camera (and no other inputs), the signal input from the camera must connect to the RCA labeled 'REAR-C'. Refer to the dipswitch settings chart to skip/enable AV sources

upon toggle switch presses (optional. Page 2).

a. If you're installing a Nav-TV CAM 6 or Handle Cam as well, the power connector plugs directly into the W204 interface port labeled 'R-CAM'.











- 13. Optional: Connect the remote eye to the port labeled 'IR' and leave it in clear view of the driver (often it can be stuck inside a vent). This connection would be necessary if you want to be able to adjust anything from the W204 interface's menu.
 - a. *While in any AV mode other than factory* (on the display screen), press the **MENU** button for **Menu 1**, **or** hold the **left arrow** to enter **MENU 2**.
 - b. To switch between AV modes, press the 'OK' button.



14. Optional: Connect the provided momentary toggle switch to the port on the W204 interface labeled 'MODE'. Pressing this switch with the ignition on will cycle the screen modes as follows: factory screen > NAVI (RGB) > AV1 > AV2 > AV3 > factory screen.

15. Note: All other included harnesses not mentioned in this manual are not needed for most installations. If you would like to know more about the full capability of this interface, contact NAV-TV tech support at 561-955-9770. Additional features not mentioned in this manual are not supported by NAV-TV at this time.

Menu Adjustments

Before you start:

PARK

UTIL


UTIL

MENU to Return

- Make sure the car's ignition is on and radio is booted/settled
- You must be in 'NAVI' (RGB), 'AV1', 'AV2' or 'AV3' mode (on display screen)
- Use the remote 'OK' button to switch modes, or use the provided input toggle switch


SAFE ENABLE

Hold the LEFT ARROW for 3 seconds. The Menu of FACTORY will appear on screen.



wire) Note: on some kits, this option is located under 'UTIL'

SAFE ENABLE: If 'ON', prevents AV sources from showing (unless you ground *Blue 'PARKING' wire*)



OK to Select

Agreement: End user agrees to use this product in compliance with all State and Federal laws. NAV-TV Corp. would not be held liable for misuse of its product. If you do not agree, please discontinue use immediately and return product to place of purchase. This product is intended for off-road use and passenger entertainment only.



01/20/14 NTV-DOC156

-The only setting that may need necessary adjustment here would be CAR MODEL (BMW/AUDI KITs) Note: on some kits, this option is

optional and install dependent.

PARK SETUP: Rear-CAM guideline **REAR SELECT:** Change *rear camera* activation from CAN to LAMP (gray

FAQs

Q. I cannot switch A/V sources.

A. Check IR or toggle switch connection. Check the LEDs on the interface, if nothing is lit up with vehicle ignition, check power/ground connections.

Q. All I see on the display is a black screen (no factory image pass-through).

A. Make sure the video cables (IN/OUT) are connected at the proper location (Screen/Radio/NAV DRIVE).

B. Make sure the video cables are seated all the way.

C. Make sure Dip Switches 5 & 6 are set correctly (resolution or screen size).

Q. Displayed image color is not proper (too dim or color seems wrong).

A. Try to select 'INITIAL' in OSD menu.

Q. Rear camera image does NOT appear.

A. Make certain Dip Switch #7 in set **down** for aftermarket camera, or **up** for a factory camera.

B. Try swapping the CAN connection wires. This will not do damage, if it is hooked up wrong it will only not work.

C. Make certain the camera is properly powered. Check voltage at the camera itself.

D. Try an alternative video source, don't assume the power/ground is correct unless you've checked it *with a multi-meter!*

E. If this is a CAN-connected module and you've connected the CAN wires, try using the gray wire (*not all interfaces have this wire!*) instead of the CAN connection for reverse activation. You'll also need to change the *Rear Select* option in the *Menu of Factory (MENU 2)* under *UTIL* or *PARK*. Refer to the *Menu Adjustments* section.

Q. Unwanted A/V mode is displayed upon a toggle press (A/V source switching order: OEM->RGB->AV1->AV2->AV3->OEM).

A. Check DIP Switch Setting. Refer to page 2.