

NAV-TV

INTERFACING THE FUTURE

3950 NW 120th Ave, Coral Springs, FL 33065 TEL 561-955-9770 FAX 561-955-9760
www.nav-tv.com info@nav-tv.com

RGB-VW

NTV-KIT389



Overview

The RGB-VW allows the user to add an aftermarket backup camera to the factory navigation screen in select Volkswagen vehicles. Reverse activation is automatic, no reverse lamp connection is required.

- **NOTE: The VW must be programmed for rear camera (VAG-Comm: Ross Tech) before installing this product.**


Kit Contents



RGB Converter
NTV-INT005




Plug & Play Video IN Harness
NTV-HAR209



RGB Power Harness
NTV-CAB034


Interface Connectors



Installation

****This car must be programmed for rear camera before installing this kit. This update can be performed at a VW dealership, or if you have a VAG-COMM programmer you can perform the update yourself.***

1. Remove the factory radio, disconnect all harnesses and set the radio aside.
2. Connect the **black wire** from the provided **RGB Power Harness** to ground.
3. Connect the **red wire** from the provided **RGB Power Harness** to an accessory 12v (+) source.
4. Connect the provided **Plug & Play Video IN Harness** to the RGB-VW.
5. Connect the other end of the **Plug & Play Video IN Harness** to the port of the back of the VW radio (it will only fit in one location).
6. Connect the power plug you previously wired up (step 2 & 3) to the RGB-VW.
7. Connect your camera's signal to port on the RGB-VW labeled '**VIDEO 1**'.



Notes:

- If you only see a black screen when you put the vehicle in reverse, flip the attached toggle. Leave the toggle in the position where the RGB-VW works properly.
- The blue wire from the RGB-VW is not used.
- The VIDEO 2 port is not used.

