

3950 NW 120th Ave, Coral Springs, FL 33065 TEL 561-955-9770 FAX 561-955-9760


www.nav-tv.com info@nav-tv.com

AUDI DYNAMIC-EXT NTV-KIT701




Overview

The AUDI-DYN EXT Kit interfaces a backup camera (with dynamic guidelines) and one additional video input (front cam, etc) to the factory media screen in select Audi vehicles with the external MMi media system (MMi controls on the console, not vertical radio face).



Agreement: End user agrees to use this product in compliance with all State and Federal laws. NAV-TV Corp. would not be held liable for misuse of its product. If you do not agree, please discontinue use immediately and return product to place of purchase. This product is intended for off-road use and passenger entertainment only.

BHM



Dip Switch Settings

Dip SW:	1	2	3	4	5	6	7	8
UP	AUX MENU OFF	CAN	CAN	RVC OFF	CAN	N/A	HI RES	KEEP DOWN
	(leave UP normally)	TYPE	TYPE		SPEED 1			
DOWN	AUX MENU ON	CAN	CAN	RVC ON	CAN	N/A	LOW RES	KEEP DOWN
	(leave UP normally)	TYPE	TYPE		SPEED 2			

YEAR	VEHICLE	1	2	3	4	5	6	7	8
Up to	A4, A5, A6,	X	X		RVC OFF	X	N/A	HIGH RES	
2010	Q5			X	RVC ON		N/A	LOW RES	X
2011+	A4, A5, Q5	X	X	X	RVC OFF	X	N/A	HIGH RES	
					RVC ON		N/A	LOW RES	X
Up to	07	X		X	RVC OFF	X	N/A	HIGH RES	
2010	Q7		X		RVC ON		N/A	LOW RES	X
2011+	Q3, Q7	X			RVC OFF		N/A	HIGH RES	
			X	X	RVC ON	X	N/A	LOW RES	X
2011+	A6, Touareg,	X	X	X	RVC OFF		N/A	HIGH RES	
	Lamborghini				RVC ON	X	N/A	LOW RES	X



Note: You must remove power to the unit prior to making adjustments to the dip switches.

AUDI-DYN-EXT Installation (A4, A5, A6, Q5)

ATTENTION INSTALLER: All connections (including CAN) must be made BEFORE connecting the power harness to this unit for proper startup operation.

- 1. Remove the factory radio (CD). Depending on the vehicle, this will require EURO tools or just prying the climate control panel from the sides (use plastic tools!). Disconnect all harnesses and set the radio aside.
- 2. Remove/drop the glovebox. This requires removing multiple 8mm bolts which secure it to the dash. *In some vehicles the pocket or single DIN media-gateway must be removed to access a bolt for removal.*
 - a. Remove this beauty panel *before dropping glove box* (newer AUDI's, beneath glove box):
- Connect the provided LVDS-IN Cable to the OEM radio at the *pink* connector (no nav) or *gray* connector (with nav). This connector is keyed and will only fit in one direction. Run the other end of this cable out to the glove box area and connect to the interface plug labeled 'VIDEO IN'.


4. Connect the <u>OEM</u> pink (or gray) circular HSD connector previously connected to the


radio (removed in step 1) to the green port on the interface labeled 'VIDEO OUT'. You may need to unwrap/cut factory tape for it reach the module with proper slack.

- 5. Reconnect remaining plugs to the radio and carefully place it back into the dash. Don't secure the radio until fully tested.
- 6. **Optional:** If this car is **not** equipped with OEM rear parking sensors, you may turn the PDC off in the OSD menu system (see page 7 for menu information).

Note: If adjusting any RVC or AUX Video menu settings, temporarily connecting the provided IR-Eye is *required*. The IR connector is located among the main power harness (2-pin

& 3-pin). See menu settings on page 7 for more info.










 Grab the provided *Power/CAN Harness* from the AUDI-DYN-EXT kit. Use the chart below to locate and solder (splice, don't cut) the following wires to the car (*you may have to extend a pair of CAN wires for Q7*):




Vehicle	Interface wires	Connect to AUDI Wire:	Wire Location		
A I I	GROUND (Black)	Brown (-)	Can Gateway or Radio		
ALL	POWER (Red)	Black/White (ACC +)	Passenger side fuse box (extend)		
A4/A5/ Q5	CAN HI (Blue)	CAN HI (Orange/Green)	CAN Gateway (Right side of radio. Must remove glove box for access.)		
	CAN LO (White)	CAN LO (Orange/Brown)	CAN Gateway (Right side of radio. Must remove glove box for access.)		
A6 or Lamborghini*	CAN HI (Blue)	CAN HI (Orange/Blue)	Climate Control (Beneath radio)		
	CAN LO (White)	CAN LO (Orange/Brown)	Climate Control (Beneath radio)		
Q3/Q7	CAN HI (Blue)	CAN HI (Orange/Black)	CAN Gateway (High in drivers dash to the left of steering wheel)		
	CAN LO (White)	CAN LO (Orange/Brown with blue dots)	CAN Gateway (High in drivers dash to the left of steering wheel)		
vw	CAN HI (Blue)	CAN HI (Orange/Green)	CAN Gateway (High in drivers dash to the left of steering wheel)		
Touareg	CAN LO (White)	CAN LO (Orange/Brown)	CAN Gateway (High in drivers dash to the left of steering wheel)		

*For Lamborghini, the CAN wires may need to be extended to reach the climate control module.



- 8. Install your reverse camera and run signal, power and ground wires up front to the AUDI interface.
- 9. Power your camera with an ACC source, not a reverse lamp trigger (the *purple* wire from the main power harness labeled *'REAR12VOUT'* provides 12v (+) when in reverse only, if you want to use a reverse signal).
- 10. Connect the signal for your camera to the yellow RCA among the *Power/CAN Harness* labeled '*CAMERA*'.
- 11. Optional: If adding an auxillary video in or front camera, connect the signal to the RCA among the Power/CAN Harness labeled 'CVBSIN'. If automatic front camera switching is desired, the setting must be activated in the OSD Menu system. See page 8.
- 12. Connect the 24-pin white plug from the *Power/CAN Harness* to the port on the AUDI 09 interface labeled *'Power/CAN'*.
- 13. UPDATE: For older AUDI's (only) that do not have the 'iNAV' button on the steering wheel and adding AUX Video/Front Camera, connect (solder) the White wire labeled 'MMI' to the MMI data wire located behind the OEM radio at the Euro-style plug, at pin 10. This wire color will vary by vehicle, but the pin location will remain the same.








Press the **NAV** button near the MMi command knob for switching to the AUX video/front camera source at any time.

14. Start the car and test for proper functionality before replacing dash pieces. If menu adjustments are needed (to remove sensor overlay, etc.), proceed to 'Menu Adjustments'

Installation Diagram

Remove the RADIO, not the screen for EXT MMI





BHM 11/21/17 NTV-DOC243

Menu Adjustments

Before you start:

- 1. The IR-Eye must be connected
- 2. Make sure the car's ignition is on and radio is on
- You must be in *Reverse Camera* mode *OR AUX Video* mode (see below):
 - Reverse Camera Mode adjusts Reverse Camera Settings
 - AUX Video Mode adjusts AUX Video Settings
- Press the OK BUTTON <u>4 times</u> (numbers will display per press), then press POWER.
- 5. The **OSD Menu** will appear on screen (auto-time out in about 5 seconds if no action occurs).





If adding a front camera OR Aux Video source:

- 1. Disconnect POWER/CAN Harness from interface
- 2. Place DIP SWITCH 1 in the DOWN position, reconnect power
- 3. Press the *iNAV* button on the steering wheel to activate 'NAV input'
- 4. Press OK button on remote 4 times, then press POWER

SET – FRON CAM must be turned on if adding a *front camera* **and the user wishes for automatic front camera switching.** Options for 5, 7, 9 or 11 seconds are user-selectable for the length of time the front camera input stays active once the vehicle is placed out of reverse.

If the user wants only an AUX video input *without front camera*, set *AV1-SEL* to *ON*

Once finished with settings, place DIP SWITCH 1 back into the **UP position** and reset power to interface.



Adding HD-LINK Adapter (HDMI Input)

Follow the instructions below when adding the HDMI adapter (HD-LINK) to enable HDMI input to the OEM screen:

- 1. Put dip switch #1 in the **DOWN** position.
- 2. Activate the 'NAV INPUT' by pressing the 'iNAV' button on the steering wheel.
- 3. Once 'NAV INPUT' shows on the screen, on the remote press the **OK BUTTON** <u>4 times</u>, then press **POWER**.
- 4. Navigate to the 'NAVI' section.
 - a. Select 'HDMI-SEL'
 - b. Choose 'HD95E'
 - c. Press *MODE* on the remote to return and exit the OSD menu (or let it time out).
- 5. Replace dip switch #1 to the **UP** position.
- 6. Connect the *black wire* to ground (-) and the *red wire* to ACC power (+) from the main power connector on the *HD-LINK* adapter. The RCA's on this plug provide audio from the HDMI source.





This module includes a green *input* wire for analog triggering of either the Reverse camera input or the 'AVIN' input (yellow RCAs), selectable through the AV menu. This allows for adding multiple cameras through the use of an SVS-6 switcher, etc. Follow the steps below adjust this feature. *NOTE: by default, the green wire will trigger the Reverse camera input RCA.*

- 1. Put dip switch #1 in the **DOWN** position. When this section is complete, return switch #1 **UP**.
- 2. Activate the 'NAV INPUT' by pressing the 'iNAV' button on the steering wheel.
- 3. Once 'NAV INPUT' shows on the screen, on the remote press the **OK BUTTON** <u>4 times</u>, then press **POWER**.
- 4. Navigate to the 'SET' section.
 - Select 'REVERSE WIRE'
 - Choose 'AV1', 'REAR' or 'REAR MODE' (explanations below)
 - Press *MODE* on the remote to return and exit the OSD menu (or let it time out).
 - Test by sending temporary power (12v +) to the *green wire* labeled *reverse*.



misuse of its product. If you do not agree, plant intended for off-road use and passenger entertainment only.



AUDI DYN-EXT Operation

- Once all connections have been properly made, placing the vehicle in reverse will show the connected rear camera image with Dynamic Guidelines which correspond with the steering wheel geometry.
- If a front camera was added and *Automatic front-camera switching* was turned on, whenever the vehicle leaves reverse (after showing reverse image once) the connected front camera will display for the user-set amount of time (5, 7, 9 or 11 seconds, see page 7 for menu settings).
- If AUX Video is wanted (*no front camera*), use the *iNAV* button on the steering wheel for AUX Video switching. The option for AUX Video must be turned on in the AUX VID Menu (see page7).



For vehicles without 'iNAV' button on the steering wheel, use the **NAV** button near the MMi command knob for switching to AUX/font camera (*MMi wire must be* connected, see page 5, step 13).



FAQs

Q. The unit will not power on, I have no indication of proper operation.

A. This module *will not* power on properly or display anything (reverse image or AUX video IN) <u>until CAN is properly connected</u>.

Q. All I see on the display is a black screen (no factory image pass-through).

A. Verify the video cables (IN/OUT) are connected at the proper location (*at the radio*).

B. Verify you're using the correct LVDS video connector (pink or gray).

C. Verify Dip Switches are set correctly.

Q. Nothing happens on the media screen when I place the vehicle in reverse.

A. Make sure DIP Switch 4 is the DOWN position (pull power from the interface first!). If still nothing, try placing DIP Switch 5 in the opposite position (pull power from the interface first!). Also, DIP Switch 8 must be DOWN, always.

B. Try a different year setting (with same model) from the Dip Switch chart.

C. Verify 12v (+) and ground to the interface.

Q. Rear camera image does NOT appear.

A. Verify Dip Switch #4 in set *down* for aftermarket camera, or *up* for a factory camera.

B. Verify the CAN wires and location of CAN connection.

C. Make certain the camera is properly powered. Check voltage at the camera itself.

D. Try an alternative video source, don't assume the power/ground is correct unless you've checked it *with a multi-meter!*

E. If this is a CAN-connected module and you've connected the CAN wires, try using the green wire instead of the CAN connection for reverse activation.

Q. Unwanted A/V mode is displayed upon a toggle press (A/V source switching order: OEM->RGB->AV1->AV2->OEM).

A. Check DIP Switch Settings. Refer to page 2.