



StreamStick by NAV-TV is a USB-powered, HI-FI Bluetooth 4.0 audio streaming module for automotive and home use. Make ANY stereo (equipped with AUX input) a Bluetooth-audio receiver!



Using the StreamStick is easy!

 Choose one of the provided cables that works best with your application and connect it to the 3.5mm port on the side. Connect the other end to the AUX-Input on your stereo. Make sure 'AUX' is selected as the source on the stereo.

 Connect the StreamStick to practically any USB port you can find (vehicle dashboard, back of TV, receiver or stand-alone USB charger). A blue LED will blink slowly when properly powered.

3. On your source device (cell phone, tablet) turn on Bluetooth in settings and select 'Search for Devices'

4. 'StreamStick-xxxx' should appear within a few seconds, connect and pair (BT icon should become bold when connected). The built-in LED will light up solid when a device is connected and ready to stream.

5. That's it! Start some music from your source device for Hi-Fidelity enjoyment!



The StreamStick will remember up to 8 devices. After 8 devices have been stored, the first (original) device paired will be forgotten.



Once a device is stored, the StreamStick will auto-pair with most devices. This process may take up to 1 minute.

Try to avoid placing the StreamStick behind dense objects, if possible – while line-of-sight isn't necessary for Bluetooth applications, you will get best results if the StreamStick is not blocked. Connect the StreamStick to practically any USB port you can find (vehicle dashboard, back of TV, receiver or stand-alone USB charger). A blue LED will blink slowly when properly powered.

Choose one of the provided cables that works best with your application and connect it to the 3.5mm port on the side. Connect the other end to the AUX-Input on your stereo. Make sure 'AUX' is selected as the source on the stereo.

The 'PAIR' button is only used if the user wants to disconnect the currently connected device and pair a different one. Press the button once, return to the next source device and make sure it is searching via Bluetooth – if the device is stored in the StreamStick it will connect and pair automatically.



NAV-TV

3950 NW 120th Ave, Coral Springs, FL 33065 USA/CAN TEL : 1.866.447.3336 INT TEL: 954.323.1010

www.navtv.com sales@navtv.com support@navtv.com

Contains FCC ID: SSSBC127-X

RoHS Compliant

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Pulse. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that Interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna; increase the separation between the equipment and receiver; Connect the equipment into an outlet on a circuit different from that to which the receiver is connected; Consult the dealer or an experienced radio/TV technician for help.

To satisfy FCC RF Exposure requirements for mobile and base station transmission devices, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during operation. To ensure compliance, operation at closer than this distance is not recommended. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industric Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lessed gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (eLr.p.) is not more than that necessary for successful communication. Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inferieur) approvué pour l'émetteur par industrie Canada. Dans le but de réduie les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfiaisante



PRODUC